

UCVD



Ultra Clean Vacuum Device

1



After removing the sampling port cap, clean the area clear of any contamination with an appropriate cloth.

2



Insert the plastic tubing into the sampling port so that the end of the tube reaches a midpoint within the oil.*

3



Remove the safety cap from the UCVD.

6



With high viscosities, oil sampling could take a couple minutes to draw. You can leave the bottle sitting in any position, even upside down.

5



After the tube is in place, simply turn the valve on the UCVD 90° to allow the vacuum to draw the oil sample into the bottle.

4



Connect the other end of the plastic tubing to the nozzle at the top of the UCVD.

7



As the oil reaches 80% capacity, pull the tubing from the oil in the sampling port and allow the remaining oil in the tube to be drawn into the bottle.

8



Once the UCVD has cleared the remaining oil in the tubing, close the valve by turning it 90° and then remove the tube.

9



Reattach the safety cap onto the UCVD.

Oil Sampling...

Made Easier.

*Ensure that the end of the tube is dipped in the oil.

